




## ► SPARE PARTS



## ► MOUNTING

Solenoid valve can be mounted in any position; vertical with coil upwards preferred.